



Note: The  $\phi 30$  holes are for access, we recommend using M10 anchor bolts that will fit into the  $\phi 16$  holes.