



Note: The ϕ 30 holes are for access, we recommend using M10 anchor bolts that will fit into the ϕ 16 holes.